







RAINSCAPES[™]

GARDEN WATERING KIT
KIT RIEGO DE JARDÍN
KIT ARROSAGE DU JARDIN

Parts List

A.		B.		E.		F.		I.		A. (50 ft.)	1/2 in. Mainline tubing
		C.								B. (3)	Outlets
		D.								C. (3)	Self-piercing caps
										D. (3)	Spikes
										E. (12)	Adjustable flow sprinkler heads
										F. (50 ft.)	1/4 in. Feeder tubing
										G. (8)	1/2 in. tubing "goof" plugs
										H. (12)	Shut-off caps
										I. (5)	1/2 in. Tubing hold down stakes

Installation & Operating Instructions

RainScapes Watering System[™] is so easy to use, you may not ever need these instructions. But if you do, just follow this step-by-step.

Step 1: Attach sprinklers to hose sections.

- To avoid kinks in the tubing, place something heavy, such as a brick, on one end of the tubing and continue to roll out the remainder. Then take a break, because you have just finished the hardest step! Tip: Lay tubing in sun to keep from recoiling.
- Connect mainline tubing to water source (such as a garden hose) or directly to outdoor faucet. For outdoor use only.
- Lay out tubing through the area you want to water.
- Grab a sprinkler from the box. They are the black spikes. Unscrew the cap from the spike by twisting the vertical grooves on the cap to the left. Repeat with remaining 2 sprinklers. Gently push the spikes into the ground at the places that you would like the sprinklers to be located. Place the tubing through the slot at the top of each spike.
- Screw self-piercing caps onto spike. Note: Goof plugs are included if you want to change later.
- Attach outlet caps to top of self-piercing caps. Note: Outlet caps may already be attached.
- Hold-down stakes are included to help put unruly tubing in its place. Add stakes between nozzles or use in areas where it is difficult to "hide" your RainScapes Watering System[™]. Push the stakes into the ground at a slight angle for the best staying power. Tip: Just cover the tubing with mulch or rock to blend into the landscape.

Step 1C



Step 1D



Step 1E&F



Step 1E&F



Step 2: Run 1/4 in. feeder tubing.

- Attach 1/4 in. feeder tubing onto one of the outlet caps.
- Use scissors to cut 1/4 in. feeder tubing so tubing is long enough to reach plants.
- Connect 1/4 in. tubing to sprinkler head with spike.
- Insert sprinkler head spike into ground near plant(s).
- Repeat for each plant/container. Multiple sprinklers may be used for large containers.
- Not all outlets need to be used. Attach shut-off caps onto any unused outlets. Keep excess shut-off caps for possible future use.

Step 1C



Step 1D



Step 1E&F



Step 1E&F



Step 3: Enjoy.

- Turn on water.
- Sprinklers have built-in flow control. Turn sprinkler heads clockwise to decrease water flow.
- Water pressure can vary. If water pressure is too high, adjust water flow at faucet. If using a long garden hose to connect the RainScapes Watering System[™], you may experience a decrease in water pressure and water flow.

Step 3B



Care and maintenance of your RainScapes Watering System™.

To ensure that your RainScapes Watering System™ lasts as long as you do, once a year, dismantle your system and flush with water to remove debris. Before freezing weather, detach the tubing from the faucet, remove the end cap, and allow the water to drain from the system. It is not necessary to store this product indoors during colder months. The RainScapes Watering System™ was designed to be run at a lower water pressure. If you have high water pressure, do not run this system with the water completely on. If you are using a long hose to connect your system to your faucet, you may experience a decrease in water pressure and the diameter of spray.

CAUTION: Shock Hazard: Do not spray near electricity. Detach from faucet during freezing weather. This product intended for outdoor watering use only. Do not use with water exceeding 100°F (38°C) or with pressures exceeding 60 psi.



Ordering information

Parts orders can be placed with:
Consumer Service
Robert Bosch Tool Corporation
1-800-635-7668
8:00 A.M. - 5:00 P.M. (CST) Mon. - Fri.
www.lrnelson.com

